

Detection of chemical substances from colorimetric sensor data using probabilistic machine learning



Lasse L. Mølgaard, Ole T. Buus, **Jan Larsen**

Hamid Babamoradi, Ida L. Thygesen, Milan Laustsen, Jens Kristian Munk, Eleftheria Dossi, Caroline O'Keeffe, Lina Lässig, Sol Tatlow, Lars Sandström, and Mogens H. Jakobsen

DREAM

The dream of an artificial nose



1207 olfactory receptor genes



1948 olfactory receptor genes



811 olfactory receptor genes




25 dyes



339 olfactory receptor genes

PRINCIPLE

Data conditioning and preprocessing – median RGB values for each dye




Extraction of color change

Dye spots are detected automatically.

RGB color changes are summarized as the relative color change to the pre-image at 0s.

The changes are small and requires sophisticated analysis.




EXPERIMENTS

Experimental setup - two target analytes are investigated


H_2O_2 - explosives precursor

- Generate different mixtures of synthetic air and analyte air samples
- Ratios between the target analyte and clean air: 0.1, 0.4, 0.7, and 1




Phenylacetone (BMK) - illegal drug precursor


- Compare colorimetric response with naturally occurring confounders, i.e., acetone, diesel, gasoline, ethanol, water, and sea water.
- Clean samples of each substance obtained as well as mixtures of BMK with each confounder was measured.



H₂O₂ dye color changes for dilution levels




Select good dyes




No single dye is sensitive enough!

DETECTION

Data processing pipeline



BMK samples PCA visualization



Classification of BMK – 10 fold cross-validation

	KNN	logist. reg.	RF (no PCA)
BMK vs. confounders	97.3%	53.2%	100%
All BMK samples vs. confounders	100%	71%	100%
Train with clean BMK and confounders/ test on BMK mixtures	53%		86%

Classification of H₂O₂ – 10 fold cross-validation


	KNN	logist. reg.	RF (no PCA)
H ₂ O ₂	94.3%	75%	95%

		KNN		log.reg.		RF	
		H ₂ O ₂	confounder	H ₂ O ₂	confounder	H ₂ O ₂	confounder
True class	H ₂ O ₂	36	4	39	1	38	2
	confounder	1	46	20	27	2	45

USE-CASE RESULTS

Detecting 100 μ l BMK in a box

- BMK end-user campaign focused on discriminating BMK from ambient air, water vapor, and acetone.
- Training on 176 samples. Expected performance evaluated on hold-out test set.



Detecting 50 mg HMTD in a box

- HMTD end-user campaign focused on discriminating HMTD from ambient air, water vapor, and H_2O_2 .
- Training on 350 samples. Expected performance evaluated using hold-out test set.

